

Instruction Manual of SKIZZE Firmware Update

1. After clicking FirmwareUpdate.exe to run the software, it will scan automatically, as shown in Figure 1:




Figure 1

2. Set the pen to update mode:

While the pen is turned off, press and hold the page up and down keys in the meantime, then click the On-Off button. When the nib turns to cyan, it enters update mode. As shown in Figure 2:




Figure 2

3. The pen will be automatically connected, then the nib's light will turn off, and the status of the software interface is shown in Figure 3:




Figure 3

4. Click the "Update" button. During the process, the progress bar shows the current upgrade progress, as shown in Figure 4:




Figure 4

5. When the progress bar is completed, the update is complete. Click "Finish" to close the software. The software interface is shown in Figure 5:




Figure 5

6. After the update is completed, the pen is in the off state. Pressing the top button for about 0.5s, the pen can be turned on normally, indicating that the update is successful.